

Description

- · good cleaning properties
- · anionic surfactant with a mild skin effect
- reduces irritant effects in SLES formulations
- foam enhancer and stabilizer in personal hygiene products
- shows a hydrotropic effect

Application

- mild shampoos
- shower gels
- bath gels
- · liquid soaps
- face wash products
- body and face scrubs
- hair sprays

- conditioners and hair straightening products
- anti-acne and anti-ageing preparations
- make-up products
- dishwashing liquids
- · laundry detergents

in line with cosmetic trends

guarantee the consumer satisfaction



improvement of Personal Care formulations

innovative product



value for money



EXOsoft L3/40

Disodium Laureth Sulfosuccinate

Chemical name	Alcohols, C10-16, ethoxylated (3), sulfosuccinates, disodium salts			
INCI name	Disodium Laureth Sulfosuccinate			
CAS number	68815-56-5			
Function	Base surfactant, foaming agent, cleansing agent			
Technical requirements	Appearance at temperature (20÷25)°C	pale yellow or yellow liquid		
	pH of 1% solution	5.0 - 6.5		
	Dry mass, % (m/m)	min. 38		
General data	Solubility in water	unlimited		
	Other solvents	ethanol, isopropyl alcohol		
	Density at 20°C, g/mL	approx 1.1		
	Molecular weight, g/mol	545		
	Viscosity at 25°C, cP	approx. 100		
	Solidification temperature, °C	approx8		
	Preservative	approx. 0.3% of Sodium Benzoate		

Classic shampoo (SZ-01)

Phase	INCI name	Brand name	Concentration [%]	Function
Α	Aqua		37.95	solvent
Α	PEG-7 Glyceryl Cocoate	ROKAcet KO300G	2.00	re-oiling agent
Α	Polyquaternium-7		2.50	contitioning agent
Α	Disodium Laureth Sulfosuccinate	EXOsoft L3/40	4.00	secondary surfactant
Α	Sodium Laureth Sulfate	SULFOROKAnol L227/1	30.00	primary surfactant
Α	Sodium Lauroyl Sarcosinate	ROKAtend LS	15.00	primary surfactant
В	Citric Acid		q.s.	pH modifier
С	PEG-120 Methyl Glucose Dioleate		1.00	thickening agent
D	Parfum		0.50	fragrance
D	Ehylhexylglycerin, Phenoxyethanol		1.00	preservative
D	Cocamidopropyl Betaine	ROKAmina K30	4.50	secondary surfactant
Е	Sodium Chloride		1.50	viscosity modifier

Appearance	visual method	turbid gel
рН		5.0 - 7.0
Viscosity [cP]	Brookfield LV, spindle: 34, speed: 2,5 RPM, T:25°C	1500 - 5000
Stability	1 month in 5°C, 20°C, 40°C,	conforms

Procedure:

- Add ingredients from phase A to the hot water (70-75°C). While mixing add ingredients one after another in the order from the table above. Mix until uniform.
- 2. Cool the batch down to at least 50°C.
- **3**. Control pH range. If necessary, adjust pH by citric acid to 5.0 7.0.
- Add PEG-120 Methyl Glucose Dioleate during mixing. Mix until uniform. Cool the batch down to at least 35°C.
- **5.** Add fragrance, preservative and cocamidopropylbetaine during mixing. Mix until uniform.
- **6.** If necessary, add Sodium Chloride to adjust the viscosity. (NOTE. Add salt (not in one go) after addition of each portion mix well).



PCC Exol SA
Sienkiewicza 4
56-120 Brzeg Dolny, Poland
products@pcc.eu

Please visit our capital group business platform

www.products.pcc.eu



April 2025

The information in the catalogue is believed to be accurate and compiled to the best of our knowledge; however, it should be considered as introductory only. Detailed information about our products is available in TDS and MSDS.

he suggestions for product applications are based on our best knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application, and for determining product suitability for the user's own purposes rests with the user.

All copyright and trademark rights, as well as other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA or PCC EXOL SA or its licensors. All rights reserved. Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce if (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply to data used in other publications, electronic information systems,