



ROKAmid MRZ4

PEG-4 Rapeseedamide

Local. Global. Integrated.

Description

- high concentration
- acts as a foam booster, strong solubilizer and emulsifier
- effective in both SLES-based and SLES-free formulations
- contains renewable rapeseed oil
- the product meets the biodegradability criteria in accordance with OECD methodology*
- easy to handle due to its low viscosity
- can also be formulated at room temperature

* Biodegradability data are based on literature sources.

Application

- shampoos
- shower gels
- hand soaps
- shaving gels
- hair styling preparations
- hair dyes



ROKAmid MRZ4 PEG-4 Rapeseedamide

Chemical name	Rapeseed oil fatty acids monoethanolamide, ethoxylated	
INCI name	PEG-4 Rapeseedamide	
CAS number	85536-23-8	
Function	Thickening agent, foam booster, solubilizer, emulsifier	
Technical requirements	Appearance at temperature (20÷25)°C	liquid
	pH of 1% solution	8 ÷ 10
	Water, %(m/m)	6.5 ÷ 8.5
	Color in Gardner scale (20÷25)°C	max. 7
	Free MEA, %(m/m)	max. 1.4
General data	Density at 25°C, g/mL	1.00
	Solubility	dispersible
	Solidification point, °C	approx. 0

Make-up removing gel [KD-203]

Phase	INCI name	Brand name	Concentration [%]	Function
A	Aqua	–	22.50	solvent
A	Glycerin	–	0.30	solvent
B	Paraffinum Liquidum	–	2.40	emollient
B	Cetearyl Alcohol	EXOalc 1618 flakes	1.80	thickener
B	Cetareth-20	ROKAnol T20	1.20	emulsifier
C	PEG-4 Rapeseedamide	ROKAmid MRZ4	4.00	surfactant
C	Parfum	–	0.50	fragrance
C	Sodium Benzoate, Potassium Sorbate	–	0.50	preservative
C	Hexylene Glycol	–	3.00	solvent
D	Acrylates/C10-30 Alkyl Acrylate Crosspolymer	–	61.60	rheology modifier
D	PPG-15 Stearyl Ether	ROKAnol SP15L	1.80	emollient
E	Sodium Hydroxide	–	0.40	pH modifier

Appearance	visual method	white gel
pH		6.0 – 6.5
Stability	1 month in 5°C, 20°C, 40°C	confirmed

Procedure:

1. Add water and glycerin into the main vessel and heat up to 80°C while mixing.
2. Combine ingredients from phase B in a separate vessel and heat up to 80°C and add to main vessel. Mix it until homogenous emulsion is obtained at 80°C.
3. Cool the batch down to 60°C while mixing and homogenize with 3000 RPM for 1 min.
4. Combine ROKAnol SP15L and Acrylates/C10-30 Alkyl Acrylate Crosspolymer and add into a main vessel. Homogenize with 3000 RPM, 60 sec.
5. At 40°C add gradually combined phase C and mix it.
6. Add Sodium Hydroxide and homogenize with 3000 RPM for 30 sec. Cool down to 25°C.

Micellar cleansing liquid [KD-205]

Phase	INCI name	Brand name	Concentration [%]	Function
A	Aqua	–	81.00	solvent
A	PEG-40 Hydrogenated Castor Oil	ROKAcet HR40W	8.00	surfactant
A	Parfum	–	0.20	fragrance
A	Sodium Benzoate, Potassium Sorbate	–	0.50	preservative
A	PEG-4 Rapeseedamide	ROKAmid MRZ4	4.00	surfactant
A	Hexylene Glycol	–	6.00	solvent
A	Citric Acid	–	0.30	pH adjuster

Appearance	visual method	transparent liquid
pH		4.5 – 5.5
Stability	1 month in 5°C, 20°C, 40°C	confirmed

Procedure:

1. Add all ingredients from phase A into one vessel and mix until homogenous solution is obtained.



This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.



PCC Exol SA

Sienkiewicza 4

56-120 Brzeg Dolny, Poland

products@pcc.eu

Please visit our capital group business platform:

www.products.pcc.eu



September 2026

The information in the catalogue is believed to be accurate and compiled to the best of our knowledge; however, it should be considered as introductory only. Detailed information about our products is available in TDS and MSDS.

The suggestions for product applications are based on our best knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application, and for determining product suitability for the user's own purposes rests with the user.

All copyright and trademark rights, as well as other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA or PCC EXOL SA or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply to data used in other publications, electronic information systems, or other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.