



SOINS PERSONNELS
SOIN DU VISAGE

GEL FOR WASHING SKIN FACE [KD-62]

FACE TREATMENT
FORMULATION ZONE

pcc

www.products.pcc.eu



*Designed with
the thought
about you*

GEL POUR LAVER LA PEAU
VISAGE [KD-62]

GEL POUR LAVER LA PEAU VISAGE [KD-62]

PHASE	NOM INCI	MARQUE	CONCENTRATION [%]	FONCTION
A	Acrylates/C10-30 Alkyl Acrylate Crosspolymer		0,90	modificateur de rhéologie
	Aqua		40,00	solvant
B	Aqua		jusqu'à	solvant
	Sodium Laureth Sulfate	SULFOROKAnol®L270/1	7,00	tensioactif
	Magnesium Laureth Sulfate	EXOsoft MG	4,00	tensioactif
	Betaine		2,00	actif
	PEG-75 Lanolin	ROKAnol® LN75 / 50	1,00	tensioactif
	Glycerin		1,00	agent hydratant
	CI 17200		q.s.	colorant
	Benzophenone-4		0,05	Filtre UV
C	Phenoxyethanol, Ethylhexylglycerin		1,00	conservateur
	Parfum		0,30	fragrance
	Cocamidopropyl Betaine	ROKAmina®K30	3,00	tensioactif
D	Sodium Hydroxide		q.s.	Ajusteur de pH



pH		5.0 - 6.0
Apparence	méthode visuelle	gel rose
Viscosité [cP]	Brookfield LV, broche 34, vitesse 2,5 RPM, T : 25°C	18000 - 22000
Stabilité	1 mois à 5°C, TA, 40°C	confirmé

Procédure:

1. Versez l'eau déionisée (25-30°C) dans le récipient principal et ajoutez le polymère croisé Acrylates/C10-30 Alkyl Acrylate. Commencez à mélanger lorsque le polymère est complètement mouillé. Mélanger jusqu'à l'obtention d'une solution homogène. Homogénéiser 1 à 2 minutes.
2. Combiner les ingrédients de la phase B dans un récipient séparé. Chauffer jusqu'à 40-45°C en agitant doucement. Mélanger jusqu'à l'obtention d'une solution homogène.
3. Ajouter lentement la phase B à la phase A en mélangeant. Mélanger jusqu'à homogénéité.
4. Ajouter le conservateur, la Cocamidopropyl Betaine et le parfum tout en mélangeant. Mélanger jusqu'à homogénéité.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

