



SOINS PERSONNELS
AUTRE



LIQUIDE DE LAVAGE ET DE
BAIN 2 en 1 POUR
NOURRISSONS [KD-21]

LIQUIDE DE LAVAGE ET DE BAIN 2 en 1 POUR NOURRISONS [KD-21]

PHASE	NOM INCI	MARQUE	CONCENTRATION [%]	FONCTION
A	Aqua		79,9	solvant
	Xanthan Gum		0,8	modificateur de rhéologie
	Glycerin		3,0	agent hydratant
B	Lactic Acid		0,3	Ajusteur de pH
	Sodium Benzoate, Potassium Sorbate		0,5	conservateur
	Betaine		2,0	actif
	Sodium Lauroyl Sarcosinate	ROKAtend LS	5,0	tensioactif
	Panthenol		0,5	actif
C	Cocamidopropyl Betaine	ROKAmina®K30K	8,0	tensioactif



Viscosité [cP]	Brookfield LV, broche 34, vitesse 2,5 RPM, T : 25°C	3000 - 9000
Stabilité	1 mois à 5°C, TA, 40°C	confirmé
Apparence	méthode visuelle	gel transparent et visqueux
pH		4.8 - 5.3

Procédure:

1. Dans un récipient principal, combiner les ingrédients de la phase A. Ajouter la gomme xanthane à la glycérine - mélanger jusqu'à obtention d'une solution homogène. Ajouter de l'eau tiède (50-55°C). Mélanger jusqu'à l'obtention d'une solution homogène. Homogénéiser 2-3 minutes.
 2. Ajouter les composants de la phase B. Mélanger jusqu'à homogénéité. Refroidir le lot à 35°C.
3. Lorsque la température du lot est de 35°C, ajouter la Cocamidopropyl Betaine pendant le mélange. Mélanger jusqu'à homogénéité.
 4. Contrôlez la plage de pH - si nécessaire, ajoutez de l'acide lactique. Bien mélanger après ajustement.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

