



CURA PERSONALE  
TRATTAMENTO VISO



SCRUB VISO IN CREMA  
[KD-91]

# SCRUB VISO IN CREMA [KD-91]

| FASE | NOME INCI                                                  | MARCHIO             | CONCENTRAZIONE [%] | FUNZIONE                    |
|------|------------------------------------------------------------|---------------------|--------------------|-----------------------------|
| A    | Ceteareth-12                                               | ROKAnol®T12         | 1,50               | emulsionatore               |
|      | Ceteareth-25                                               | ROKAnol® T25        | 0,50               | emulsionatore               |
|      | Cetearyl alcohol                                           | ExoAlc 1618 fiocchi | 3,00               | stabilizzatore di emulsione |
|      | PPG-15 Stearyl ether                                       | ROKAnol® SP15L      | 6,00               | emolliente                  |
|      | Caprylic/Capric Triglyceride                               |                     | 1,00               | emolliente                  |
|      | Helianthus Annuus Seed Oil                                 |                     | 5,00               | emolliente                  |
|      | Butyrospermum Parkii Butter                                |                     | 0,50               | emolliente                  |
|      | Tocopheryl Acetate                                         |                     | 0,20               | attivo                      |
| B    | Aqua                                                       |                     | 73,68              | solvente                    |
|      | Betaine                                                    |                     | 1,00               | attivo                      |
|      | Glycerin                                                   |                     | 4,00               | solvente                    |
|      | Pentylene Glycol                                           |                     | 2,00               | solvente                    |
|      | Magnesium Aluminum Silicate                                |                     | 0,10               | modificatore di reologia    |
| C    | Acrylates/C10-30 Alkyl Acrylate Crosspolymer               |                     | 0,27               | modificatore di reologia    |
| D    | Phenoxyethanol, Methylparaben, Ethylparaben, Propylparaben |                     | 0,50               | conservante                 |
|      | Sodium Hydroxide                                           |                     | 0,10               | regolatore di pH            |
| E    | Parfum                                                     |                     | 0,30               | fragranza                   |
|      | Cellulose acetate                                          |                     | 0,35               | abrasivo                    |



|           |                        |                                   |
|-----------|------------------------|-----------------------------------|
| pH        |                        | 5.0 - 7.0                         |
| Aspetto   | metodo visivo          | emulsione con particelle di scrub |
| Stabilità | 1 mese a 5°C, TA, 40°C | confermato                        |

## Procedura:

1. In un recipiente principale unire gli ingredienti della fase B. Aggiungere all'acqua glicole pentilenico, glicerina e betaina. Aggiungere il silicato di alluminio e magnesio durante la miscelazione. Mescolare per 10 min - 150-200 RPM. Omogeneizzare con 2000-3000 RPM, 5-6 min.
2. Aggiungere Acrylates/C10-30 Alkyl Acrylate Crosspolymer durante la miscelazione. Mescolare per 10 min - 100-150 RPM. Omogeneizzare a 700-1000 RPM, 60-90 sec.
3. In un recipiente separato unire gli ingredienti della fase A.
4. Riscaldare le fasi A e B a 75-80°C.
5. Aggiungere A in B, durante la miscelazione mantenere A/B a 75-80°C. Omogeneizzare con 2000-3000 RPM, 120 sec.
6. Raffreddare il lotto fino a 50°C durante la miscelazione. Aggiungere gli ingredienti della fase D durante la miscelazione. Omogeneizzare a 2500-3000 RPM, 120 sec.
7. Raffreddare il lotto fino a 25°C durante la miscelazione.
8. Aggiungere Parfum e abrasivo durante la miscelazione. Mescolare fino a uniformare.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform  
to check full range of products for personal care.

**[www.products.pcc.eu](http://www.products.pcc.eu)**

PCC Group  
Sienkiewicza 4  
56-120 Brzeg Dolny  
Poland

e-mail: [products@pcc.eu](mailto:products@pcc.eu)

