



PERSONAL CARE
OTHER



ANTIPERSPIRANT [KD-155]

ANTIPERSPIRANT [KD-155]

PHASE	INCI NAME	BRAND NAME	CONCENTRATION [%]	FUNCTION
A	Aqua		80	solvent
	Hydroxypropyl Starch Phosphate		1	rheology modifier
B	Cetearyl Alcohol, Cetareth-20	EXOcare®TE20 Flakes	5	emulsifier
	PPG-15 Stearyl ether	ROKAnol® SP15L	4	emollient
C	Aluminum Chlorohydrate		10	antiperspirant



Stability	1 month at 5°C, 20°C, 40°C	confirmed
Apperance	visual method	white emulsion
pH		3.5 – 5.0

Procedure:

1. In separate vessels combine ingredients from phase A and B. Homogenize phase A:1500-2000 RPM 90-120 s.
 2. Heat phase A and B to 75-80°C.
 3. Add phase B to A while mixing. Homogenize: 1500-2000 RPM 90-120 s.
4. Cool batch down to 30°C while mixing.
 5. Add phase C ingredient while mixing. Homogenize: 1500-2000 RPM 90-120 s.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

