



PERSOONLIJKE VERZORGING
SCHEERPRODUCTEN

UNIVERSELE AFTERSCHEERLOTION [KD-347]



UNIVERSELE AFTERSCHEERLOTION [KD-347]

FASE	INCI NAAM	MERKNAAM	CONCENTRATIE [%]	FUNCTIE
A	Aqua		tot	oplosmiddel
	Allantoin		0,20	actief
B	Polysorbate 80	ROKwinol 80	1,50	emulgator
	PPG-5-Ceteth-20		1,00	verzachtend
	Paraffinum Liquidum		2,50	verzachtend
C	PPG-15 Stearyl ether	ROKAnol® SP15L	1,50	verzachtend
	Carbomer		0,25	reologie modifier
D	Sodium Hydroxide		0,35	pH-regelaar
E	Phenoxyethanol, Ethylhexylglycerin		0,80	conserveermiddel
F	Aluminum Starch Octenylsuccinate		1,00	absorberend
G	Parfum		0,50	geur
H	Alcohol		3,00	oplosmiddel



stabiliteit	1 maand bij 5°C, 20°C, 40°C	bevestigd
Uiterlijk	visuele methode	witte emulsie
pH		5,0 – 7,0

Procedure:

1. Combineer ingrediënten uit fase A en B in aparte vaten.
 2. Voeg tijdens het mixen fase B toe aan fase A. Homogeniseren 60-90 sec. Combineer de ingrediënten uit fase C in een apart vat. Meng tot een uniform mengsel.
 3. Voeg fase C toe tijdens het mixen. Homogeniseren met 2500-3500 RPM, 45 sec.
4. Voeg tijdens het mixen fase D toe. Homogeniseren met 2500-3000 RPM, 45 sec.
 5. Voeg fase E t/m F-ingrediënten toe tijdens het mixen. Homogeniseren met 2500-3500 RPM, 90 sec.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

