



CURA PERSONALE
TRATTAMENTO VISO

MOUSSE DETERGENTE VISO ALLO ZINCO [RD-23]



MOUSSE DETERGENTE VISO ALLO ZINCO [RD-23]

FASE	NOME INCI	MARCHIO	CONCENTRAZIONE [%]	FUNZIONE
A	Sodium Cocoyl Isethionate		14,000	tensioattivo
	Zinc Coceth Sulfate	exosoft-zn	1,200	tensioattivo
	Cocamidopropyl Betaine	ROKAmina®K30	2,000	tensioattivo
	Aqua		52,500	solvente
B	Glycerin		18,000	attivo
	Sorbitol		10,000	attivo
	Allantoin		1,000	attivo
C	Parfum		0,200	fragranza
	CL 45100		0,002	colorante
	CL 42090		0,001	colorante
D	Sodium Benzoate		0,500	conservante
	Potassium Sorbate		0,300	conservante
E	Lactic Acid		0,300	modificatore di pH



Stabilità	1 mese a 5°C, 20°C, 40°C	confermato
Aspetto	metodo visivo	pasta viola
pH		5,0-5,5

Procedura:

1. Aggiungere gli ingredienti della fase A all'acqua calda (40-45°C). Mescolare fino ad ottenere una soluzione omogenea.
 2. Raffreddare il batch fino ad almeno 35°C.
 3. Aggiungere la fase B durante la miscelazione. Mescolare fino ad ottenere una soluzione omogenea.
4. Aggiungere gli ingredienti della fase CE durante la miscelazione, mescolare fino a ottenere un composto uniforme.
 5. Regolare il pH con acido lattico a 5,0-5,5



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

