



SOINS PERSONNELS
TRAITEMENT CAPILLAIRE

**CIRE GEL CAPILLAIRE FORTE
[KD-381]**



CIRE GEL CAPILLAIRE FORTE [KD-381]

PHASE	NOM INCI	MARQUE	CONCENTRATION [%]	FONCTION
A	Aqua		jusqu'à	solvant
	Glycerin		0,5	solvant
	PPG-5-Ceteth-20	ROKAnol	0,5	tensioactif
A1	PVP		1,0	fixation des cheveux
	PVP		1,0	fixation des cheveux
B	Steareth-20	ROKAnol	32,0	émulsifiant
C	Phenoxyethanol, Ethylhexylglycerin		0,5	conservateur



Stabilité	1 mois à 5°C, 20°C, 40°C	confirmé
Apparence	méthode visuelle	gel clair et collant
pH		5,0 – 7,5

Procédure:

1. Dans un récipient séparé, mélanger les ingrédients des phases A, A1.
 2. Préparez les autres ingrédients – phases B et C.
 3. Chauffer les phases A et B à 75-80°C.
 4. Ajouter lentement la phase A1 à la phase A tout en mélangeant. Maintenir la température (phase A/A1) à 75-80°C.
 5. Ajouter très lentement le ROKanol S20 (ajouter une petite portion en mélangeant. Attendre jusqu'à homogénéité) à la phase A/A1 pendant le mélange. Maintenir la température de 75-80°C jusqu'à dissolution.
6. Ajouter la phase C en mélangeant.
 7. Refroidissez le lot à 70°C.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

