



CURA PERSONALE
TRATTAMENTO VISO

MILD EMULSION FOR SKIN FACE [ST-03]

FACE TREATMENT
FORMULATION ZONE

pcc

www.products.pcc.eu



*Designed with
the thought
about you.*

EMULSIONE DELICATA
PER LA PELLE DEL VISO
[ST-03]

EMULSIONE DELICATA PER LA PELLE DEL VISO [ST-03]

FASE	NOME INCI	MARCHIO	CONCENTRAZIONE [%]	FUNZIONE
A	Paraffinum Liquidum		1,5	emolliente
	Butyrospermum Parkii (Shea Butter)		0,5	emolliente
	Caprylic/Capric Triglyceride		1,0	emolliente
	Glyceryl Stearate, PEG- 100 Stearate		3,0	emulsionatore
	Cetearyl alcohol		2,5	co- emulsionante
B	Aqua		25,3	solvente
C	Xanthan Gum		0,4	modificatore di viscosità
	Glycerin		1,3	agente idratante
	Aqua		50,2	solvente
D	Citric acid		0,1	modificatore di pH
	Sodium Lauroyl Glycinate	ROKAtend GL	5,0	tensioattivo
	Sodium Lauroyl Sarcosinate	ROKAtend LS	7,7	tensioattivo
	Parfum		0,5	fragranza
	Phenoxyethanol, Methylparaben, Ethylparaben, Propylparaben		1,0	conservante



pH		6.5 - 7.5
Aspetto	metodo visivo	emulsione bianca
Viscosità [cP]	Brookfield LV, mandrino 34, velocità 6,0 RPM, T: 25°C	5000 - 10000
Stabilità	1 mese a 5°C, TA, 40°C	confermato

Procedura:

1. In un recipiente principale riscaldare tutti gli ingredienti a 75-80°C e fare lo stesso con la fase B.
2. Versare l'acqua calda della fase B nella fase A, mescolare bene (evitare il raffreddamento) e omogeneizzare per 5 minuti. Quindi, iniziare a raffreddare la formulazione e ripetere l'omogeneizzazione a 60°C. Procedere allo stesso modo a 40°C.
3. Contemporaneamente preparare la fase C miscelando Xanthan Gum, Glicerina e acqua tiepida (50°C). Per ottenere una soluzione omogenea, omogeneizzare per 1 min.
4. Unire gli ingredienti della fase D e mescolare fino a ottenere un composto uniforme. Se necessario, aggiungere acido citrico.
5. Aggiungere le fasi D e B al recipiente principale (fase A) e miscelare per 5 min, quindi omogeneizzare per 1 min.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

