



PERSONLIG VÅRD
ANSIKTSBEHANDLING

MILD GEL TO SKIN FACE WASHING [KD-61]

FACE TREATMENT
FORMULATION ZONE

pcc

www.products.pcc.eu



*Designed with
the thought
about you.*

MILD GEL TILL HUDEN
ANSIKTSTVÄTTNING
[KD-61]

MILD GEL TILL HUDEN ANSIKTSTVÄTTNING [KD-61]

FAS	INCI NAMN	VARUMÄRKE	KONCENTRATION [%]	FUNGERA
A	Aqua		50,00	lösningsmedel
	Acrylates/C10-30 Alkyl Acrylate Crosspolymer		0,85	reologimodifierare
B	Aqua		upp till	lösningsmedel
	Disodium Laureth Sulfosuccinate	EXOsoft L3/40	5,00	tensid
	Cocamidopropyl Betaine	ROKamina®K30	6,00	tensid
	Betaine		1,00	aktiva
	Glycerin		1,00	fuktgivande medel
	PEG-7 Glyceryl Cocoate	rokacet-ko300g	0,50	tensid
	CI 42090		q.s.	färgämne
	Benzophenone-4		0,05	UV-filter
C	Phenoxyethanol, Ethylhexylglycerin		1,00	konserveringsmedel
	Parfum		0,30	doft
	Sodium Hydroxide		0,50	pH-justerare



Stabilitet	1 månad vid 5°C, RT, 40°C	bekräftad
Utseende	visuell metod	klar, blå viskös gel med suspenderade luftbubblor
pH		5.0 – 6.0

Procedur:

1. Häll det varma avjoniserade vattnet (40-50°C) i huvudkärlet och tillsätt Acrylates/C10-30 Alkyl Acrylate Crosspolymer. Börja blanda när polymeren är helt blöt. Blanda tills den homogena lösningen erhålls.

2. Kombinera ingredienser från fas B i ett separat kärl. Värm upp till 30°C med försiktig omrörning. Blanda tills homogen lösning erhålls.
3. Tillsätt fas B till fas A. Blanda tills homogen lösning erhålls. Kyl satsen ner till 30°C.

4. När batchtemperaturen är 30°C, tillsätt konserveringsmedel, parfym och natriumhydroxid. Blanda i 20 minuter med långsam omrörning.

5. Justera det slutliga pH-värdet till 5,0 – 6,0 med tillsats av natriumhydroxid (30 %) vid behov.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

