



SOINS PERSONNELS
AUTRE

MOUSSE CORPS POUR ENFANTS [RD-09]



MOUSSE CORPS POUR ENFANTS [RD-09]

PHASE	NOM INCI	MARQUE	CONCENTRATION [%]	FONCTION
A	Aqua		44,600	solvant
	Sodium Cocoyl Isethionate		12,000	tensioactif
	Sodium Lauroyl Sarcosinate	ROKAtend LS	4,500	tensioactif
	Coco-betaine	ROKAmina®K30B	1,000	tensioactif
	C12-15 Alkyl Benzoate	EXOsoft AB25	1,000	agent hydratant
B	Glycerin		25,000	actif
	Sorbitol		10,000	actif
	Panthenol		1,000	actif
C	Parfum		0,200	fragrance
	CL 17200		0,001	colorant
D	Sodium Benzoate		0,500	conservateur
	Potassium Sorbate		0,300	conservateur
E	Lactic Acid		0,300	modificateur de pH



Stabilité	1 mois à 5°C, 20°C, 40°C	confirmé
Apparence	méthode visuelle	pâte rose
pH		5.0 - 5.5

Procédure:

1. Ajouter les ingrédients de la phase A dans de l’eau tiède (40-45°C). Remuer jusqu’à l’obtention d’une solution homogène.
 2. Refroidir le lot à au moins 35°C.
 3. Ajouter les ingrédients de la phase B tout en mélangeant. Remuer jusqu’à l’obtention d’une solution homogène.
4. En remuant constamment, ajouter les ingrédients de la phase CE. Mélanger jusqu’à l’obtention d’une consistance homogène.
 5. Ajuster le pH avec de l’acide lactique à un niveau de 5,0 à 5,5.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

