



OSOBNÁ STAROSTLIVOSŤ
OŠETRENIE TVÁRE

MAKE-UP REMOVING MILK [KD-85]

FACE TREATMENT
FORMULATION ZONE

pcc

www.products.pcc.eu



*Designed with
the thought
about you.*

MLIEKO NA
ODSTRAŇOVANIE MLIEKO
[KD-85]

MLIEKO NA ODSTRAŇOVANIE MLIEKO [KD-85]

FÁZA	INCI MENO	NÁZOV ZNAČKY	KONCENTRÁCIA [%]	FUNKCIA
A	Ceteareth-12	ROKAnol®T12	1,00	emulgátor
	Ceteareth-25	ROKAnol® T25	1,00	emulgátor
	Cetearyl alcohol		2,00	stabilizátor emulzie
	PPG-15 Stearyl ether	ROKAnol® SP15L	5,00	zmäkčujúci
	Helianthus Annuus Seed Oil		1,00	zmäkčujúci
	Caprylic/Capric Triglyceride		2,00	zmäkčujúci
B	Aqua		83,35	solventný
	Betaine		0,50	aktívny
C	Glycerin		1,00	hydratačný prostriedok
	Xanthan Gum		0,05	upravovač pH
D	Carbomer		0,25	modifikátor reológie
E	Sodium Hydroxide		0,05	upravovač pH
	Phenoxyethanol, Methylparaben, Ethylparaben, Propylparaben		0,80	konzervačný prostriedok
F	PEG-7/PPG-2 Propylheptyl ether	ROKAnol GA7LAW	2,00	solventný



pH	5.0 – 7.0	
Vzhľad	vizuálna metóda	biela emulzia
Stabilita	1 mesiac pri 5 °C, RT, 40 °C	potvrdil

Postup:

1. V samostatnej nádobe zmiešam zložky z fázy A, B a C.
2. Pridávajte pomaly zložky fázy D do fázy B za miešania. Miešajte, kým nebude jednotná.
3. Pridávajte pomaly zložky fázy C do fázy B počas miešania. Homogenizácia s 2000-3000 otáčkami za minútu, 90 sekúnd.
4. Zahrejte fázy A a B na 75-80 °C.
5. Pridajte A do B, dobre premiešajte ručným miešaním, udržiavajte A/B pri 75-80 °C. Homogenizácia s 2000-3000 otáčkami za minútu, 120 sekúnd.
6. Počas miešania sa dávka ochladí na 50 °C. Počas miešania pridajte zložky fázy E. Homogenizácia pri 2500-3500 ot./min., 90 sekúnd.
7. Násada sa ochladí na 25 °C. Počas miešania pridajte zložky fázy F. Homogenizácia pri 2500-3500 ot./min., 90 sekúnd.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

