



CURA PERSONALE
TRATTAMENTO VISO



**DETERGENTE VISO CON
SCHIUMA BIFASE
[ST-05]**

DETERGENTE VISO CON SCHIUMA BIFASE [ST-05]

FASE	NOME INCI	MARCHIO	CONCENTRAZIONE [%]	FUNZIONE
A	Aqua		38,4	solvente
	Sodium Lauroyl Glycinate	ROKAtend GL	10,0	tensioattivo
	Sodium Lauroyl Sarcosinate	ROKAtend LS	30,0	tensioattivo
	Propylene Glycol		3,0	solvente
	Parfum		0,6	fragranza
	Ethylhexyl Glycerine, Phenoxyethanol		1,0	conservante
	PEG-7 Glyceryl Cocoate	rokacet-ko300g	1,6	agente rilubrificante
	Mineral Oil		15,0	emolliente
	Citric acid		0,4	modificatore di pH



pH		6.0 – 7.5 (water phase)
Aspetto	metodo visivo	liquido limpido e incolore
Stabilità	1 mese a 5°C, TA, 40°C	confermato

Procedura:

1. Aggiungere gli ingredienti della fase A all'acqua calda (40-50°C). Mescolare fino a uniformare.
 2. Quindi, raffreddare la miscela a temperatura ambiente prima di aggiungere un conservante e aggiungere il resto degli ingredienti.
 3. Controllare l'intervallo di pH – se necessario, aggiungere acido citrico. Mescolare bene dopo la regolazione.
4. Aggiungere cloruro di sodio per regolare la viscosità. NOTA. Aggiungere il sale (non in una volta sola) – dopo l'aggiunta di ogni porzione mescolare bene.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

