



SOINS PERSONNELS
SOIN DU VISAGE

MOUSSE NETTOYANTE POUR LE VISAGE AU ZINC [RD-23]



MOUSSE NETTOYANTE POUR LE VISAGE AU ZINC [RD-23]

PHASE	NOM INCI	MARQUE	CONCENTRATION [%]	FONCTION
A	Sodium Cocoyl Isethionate		14,000	tensioactif
	Zinc Coceth Sulfate	exosoft-zn	1,200	tensioactif
	Cocamidopropyl Betaine	ROKamina®K30	2,000	tensioactif
	Aqua		52,500	solvant
B	Glycerin		18,000	actif
	Sorbitol		10,000	actif
	Allantoin		1,000	actif
C	Parfum		0,200	fragrance
	CL 45100		0,002	colorant
	CL 42090		0,001	colorant
D	Sodium Benzoate		0,500	conservateur
	Potassium Sorbate		0,300	conservateur
E	Lactic Acid		0,300	modificateur de pH



Stabilité	1 mois à 5°C, 20°C, 40°C	confirmé
Apparence	méthode visuelle	pâte violette
pH		5,0-5,5

Procédure:

1. Ajouter les ingrédients de la phase A à l'eau tiède (40-45°C). Mélanger jusqu'à l'obtention d'une solution homogène.
2. Refroidir le lot à au moins 35°C.
3. Ajouter la phase B pendant le mélange. Mélanger jusqu'à l'obtention d'une solution homogène.
4. Ajouter les ingrédients de la phase CE tout en mélangeant jusqu'à homogénéité.
5. Ajuster le pH par l'acide lactique à 5,0-5,5



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

