



SOINS PERSONNELS
AUTRE



LIQUIDE DE LAVAGE ET DE
BAIN 2 en 1 POUR
NOURRISSONS [KD-22]

LIQUIDE DE LAVAGE ET DE BAIN 2 en 1 POUR NOURRISSONS [KD-22]

PHASE	NOM INCI	MARQUE	CONCENTRATION [%]	FONCTION
A	Aqua		82,25	solvant
	Lauryl Glucoside		2,00	tensioactif
	Betaine		1,00	actif
	Glycerin		4,00	agent hydratant
	Lactic Acid		0,50	Ajusteur de pH
	Sodium Benzoate, Potassium Sorbate		0,50	absorbant
B	Sodium Lauroyl Sarcosinate	ROKAtend LS	4,00	tensioactif
	Panthenol		0,25	actif
C	PEG-120 Methyl Glucose Dioleate		0,50	épaississant
D	Cocamidopropyl Betaine	ROKAmina®K30	5,00	tensioactif



Viscosité [cP]	Brookfield LV, broche 34, vitesse 2,5 RPM, T : 25°C	3000 - 9000
Stabilité	1 mois à 5°C, TA, 40°C	confirmé
Apparence	méthode visuelle	gel visqueux et trouble
pH		4.8 - 5.3

Procédure:

- Mélanger les ingrédients de la phase A. Ajouter les ingrédients de la phase A à l’eau tiède (55-60°C). Mélanger jusqu’à l’obtention d’une solution homogène. Refroidir le lot à au moins 50°C.
 - Ajouter les ingrédients de la phase B pendant le mélange. Mélanger jusqu’à homogénéité.
- Ajouter PEG-120 Methyl Glucose Dioleate tout en mélangeant. Mélanger jusqu’à homogénéité. Refroidir le lot à au moins 30°C.
 - Ajouter Cocoamidopropyl Bétaïne tout en mélangeant. Mélanger jusqu’à homogénéité.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

