



CUIDADO PERSONAL
TRATAMIENTO FACIAL



LIMPIADOR DE CARA
CON ESPUMA BIFÁSICO
[ST-05]

LIMPIADOR DE CARA CON ESPUMA BIFÁSICO [ST-05]

FASE	NOMBRE INCI	NOMBRE DE LA MARCA	CONCENTRACIÓN [%]	FUNCIÓN
A	Aqua		38,4	solvente
	Sodium Lauroyl Glycinate	ROKAtend GL	10,0	surfactante
	Sodium Lauroyl Sarcosinate	ROKAtend LS	30,0	surfactante
	Propylene Glycol		3,0	solvente
	Parfum		0,6	fragancia
	Ethylhexyl Glycerine, Phenoxethanol		1,0	preservativo
	PEG-7 Glyceryl Cocoate	rokacet-ko300g	1,6	agente de relubricación
	Mineral Oil		15,0	emoliente
	Citric acid		0,4	modificador de pH



pH		6.0 - 7.5 (water phase)
apariencia	metodo visual	líquido transparente e incoloro
Estabilidad	1 mes a 5°C, TA, 40°C	confirmado

Procedimiento:

1. Agregue los ingredientes de la fase A al agua tibia (40-50°C). Mezclar hasta que quede uniforme.
 2. Luego, enfríe la mezcla a temperatura ambiente antes de agregar un conservante y agregue el resto de los ingredientes.
 3. Controle el rango de pH; si es necesario, agregue ácido cítrico. Mezcle bien después del ajuste.
4. Agregue cloruro de sodio para ajustar la viscosidad. NOTA. Agregue sal (no de una sola vez); después de agregar cada porción, mezcle bien.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

