



CUIDADO PESSOAL
PRODUTOS DE BARBEAR

LOÇÃO DEPOIS DE BARBA [KD-147]



LOÇÃO DEPOIS DE BARBA [KD-147]

ESTÁGIO	NOME DA INCI	MARCA	CONCENTRAÇÃO [%]	FUNÇÃO
A	Cetearyl Alcohol and Ceteareth-20	Flocos EXOcare®TE20	4,0	emulsificante
	Glycine Soja Oil		1,0	emoliente
	Dimethicone		1,0	emoliente
	PPG-15 Stearyl ether	ROKAnol® SP15L	2,0	emoliente
B	Aqua		83,8	solvente
	Betaine		1,0	ativo
	Allantoin		0,1	ativo
C	Carbomer		0,2	modificador de reologia
	PPG-15 Stearyl ether	ROKAnol® SP15L	0,5	emoliente
	Cyclopentasiloxane		1,0	emoliente
D	Sodium Hydroxide		0,1	ajustador de pH
E	Phenoxyethanol, Ethylhexylglycerin		0,8	conservante
F	Aluminum Starch Octenylsuccinate		1,0	absorvente
	Parfum		0,5	fragrância
G	Alcohol		3,0	solvente



pH	5.0 - 7.0	
Aparência	método visual	emulsão branca
estabilidade	1 mês a 5°C, 20°C, 40°C	confirmado

Procedimento:

1. Em recipientes separados, misture os ingredientes das fases A e B. Aqueça até 75-80°C
 2. Adicione a fase A à fase B enquanto mistura. Homogeneizar 60-90 seg. Em um recipiente separado, combine os ingredientes da fase C. Misture até ficar homogêneo.
 3. Resfrie o lote até 60°C enquanto mistura. Adicione os ingredientes das fases C e D enquanto mistura. Homogeneizar com 2500-3500 RPM, 90 seg.
4. Resfrie o lote até 40-50°C enquanto mistura. Adicione os ingredientes das fases D, E e F enquanto mistura. Homogeneizar com 2500-3500 RPM, 90 seg. Resfrie o lote até 30°C enquanto mistura.
 5. Adicione as fases F e G enquanto mistura. Homogeneizar com 2500-3500 RPM, 90 seg



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

