



CUIDADO PESSOAL
PRODUTOS DE BARBEAR



GEL DE BARBEAR PARA
HOMENS [KD-142]

GEL DE BARBEAR PARA HOMENS [KD-142]

ESTÁGIO	NOME DA INCI	MARCA	CONCENTRAÇÃO [%]	FUNÇÃO
A	Aqua		até	solvente
	Carbomer		0,4000	modificador de reologia
	Allantoin		0,2000	ativo
	Glycerin		3,0000	solvente
	CI 42090		0,0001	Corante
B	Sodium Hydroxide		0,3000	ajustador de pH
C	Sodium Polyacrylate, Ethylhexyl Stearate, Trideceth-6		1,0000	modificador de reologia
	PPG-15 Stearyl ether	ROKAnol® SP15L	4,0000	emoliente
	PPG-5-Ceteth-20	ROKAnol®LP6066	1,0000	emoliente
	Dimethicone		1,0000	emoliente
	Phenoxyethanol, Ethylhexylglycerin		1,0000	conservante



estabilidade	1 mês a 5°C, 20°C, 40°C	confirmado
Aparência	método visual	gel opaco azul
pH		5,0 – 7,0

Procedimento:

1.

Combine os ingredientes da fase A. Adicione lentamente Carbomer à água enquanto mistura. Misture até ficar uniforme. Adicione outros componentes da fase A. Homogeneizar com 2.000-3.000 RPM, 90-120 seg.
2.

Adicione Hidróxido de Sódio enquanto mistura. Misture até ficar uniforme.
3.

Adicione os ingredientes da fase C enquanto mistura. Homogeneizar com 2.000-3.000 RPM, 120-180 seg.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

