



PERSONLIG VÅRD
ANSIKTSBEHANDLING

MILD PEARLING GEL FOR SKIN FACE [ST-06]

FACE TREATMENT
FORMULATION ZONE

pcc

www.products.pcc.eu



*Designed with
the thought
about you.*

MILD PEARLING GEL FÖR
HUDANSIKTE [ST-06]

MILD PEARLING GEL FÖR HUDANSIKTE [ST-06]

FAS	INCI NAMN	VARUMÄRKE	KONCENTRATION [%]	FUNGERA
A	Aqua		45,90	lösningsmedel
	Xanthan Gum		0,65	viskositetsmodifierare
	Glycerin		2,00	fuktgivande medel
	Sodium Benzoate, Potassium Sorbate		0,60	konserveringsmedel
B	Aqua		15,70	lösningsmedel
	Magnesium Laureth Sulfate	EXOsoft MGB	20,00	tensid
	Sodium Lauroyl Sarcosinate	ROKAtend LS	10,00	tensid
	Cocamidopropyl Betaine	ROKamina®K30	3,40	tensid
C	Citric acid		0,25	pH-modifierare
	Sodium Laureth Sulfate and Cocamide DEA and Glycol Distearate	EXOpearl N	1,00	pärlnedel
	Parfum		0,50	doft



pH		4.8 - 5.5
Utseende	visuell metod	trögflytande pärlgel
Viskositet [cP]	Brookfield LV, spindel 34, hastighet 4,0 rpm, T: 25°C	6000 - 9000
Stabilitet	1 månad vid 5°C, RT, 40°C	bekräftad

Procedur:

1. Blanda ingredienserna från fas A i ett huvudkärl. Tillsätt Xantangummi till glycerin - blanda tills en homogen lösning erhålls. Tillsätt varmt vatten (40-50°C) och konserveringsmedel. Blanda tills homogen lösning erhålls. Homogenisera i 2-3 minuter.

2. Kombinera ingredienser från fas B. Tillsätt ingredienser från fas B till varmt vatten (40-45°C). Blanda tills homogen lösning erhålls.
3. Tillsätt fas B till fas A. Blanda tills homogen lösning erhålls. Kyl satsen ner till 30°C.

4. Justera pH till 4,8 - 5,5 genom att använda citronsyra. Blanda väl efter justering.

5. Tillsätt ingredienser från fas C. Blanda tills en homogen lösning erhålls.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

