



CURA PERSONALE  
TRATTAMENTO VISO

## CREMA GIORNO IDRATANTE PROFONDA [IC-07]



# CREMA GIORNO IDRATANTE PROFONDA [IC-07]

| FASE | NOME INCI                                  | MARCHIO        | CONCENTRAZIONE [%] | FUNZIONE                    |
|------|--------------------------------------------|----------------|--------------------|-----------------------------|
| A    | Aqua                                       |                | 78,1               | solvente                    |
|      | Glycerin                                   |                | 3,0                | umettante                   |
|      | Trehalose, Hydrolyzed<br>Vegetable Protein |                | 1,0                | attivo                      |
|      | Propanediol, Aqua,<br>Bacillus ferment     |                | 1,0                | attivo                      |
|      | Panthenol                                  |                | 1,0                | attivo                      |
|      | Sclerotium Gum,<br>Xanthan Gum             |                | 0,4                | modificatore di<br>reologia |
| B    | Cetearyl alcohol                           |                | 2,0                | emulsionatore               |
|      | Ceteareth-20                               | ROKAnol®T20    | 2,0                | emulsionatore               |
| C    | C12-15 Alkyl Benzoate                      | EXOsoft AB25   | 6,0                | emolliente                  |
|      | PPG-15 Stearyl ether                       | ROKAnol® SP15L | 4,0                | emolliente                  |
|      | Phenoxyethanol                             |                | 0,8                | conservante                 |
|      | Tocopherol                                 |                | 0,6                | attivo                      |
|      | Sodium Polyacrylate                        |                | 0,4                | modificatore di<br>reologia |
|      | Parfum                                     |                | 0,2                | fragranza                   |



|         |               |                  |
|---------|---------------|------------------|
| Aspetto | metodo visivo | emulsione bianca |
| pH      |               | 5.0 – 7.0        |

## Procedura:

1. In un becher mescolare lo sclerozio, la gomma di xantano con la glicerina.
  2. In un altro becher unire Aqua con la sostanza attiva (fase A). Mescolare e riscaldare fino a 60 – 70°C. Aggiungere Sclerotium e Xanthan Gum con Glycerin.
  3. Nel recipiente principale mescolare la fase B e riscaldare fino a 60 – 70 °C.
  4. Aggiungere la fase A alla fase B e omogeneizzare a 2500 – 3500 giri/min, 90 – 120 sec. Raffreddare il lotto a 40°C durante la miscelazione.
5. Mescolare il poliacrilato di sodio con EXOsoft AB25. Aggiungere la fase rimanente C e mescolare.
  6. Aggiungere la fase C al becher principale, mescolare e omogeneizzare a 2500 – 3500 giri/min, 90 – 120 secondi.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform  
to check full range of products for personal care.

**[www.products.pcc.eu](http://www.products.pcc.eu)**

PCC Group  
Sienkiewicza 4  
56-120 Brzeg Dolny  
Poland

e-mail: [products@pcc.eu](mailto:products@pcc.eu)

