



SOINS PERSONNELS
TRAITEMENT CAPILLAIRE



**SHAMPOOING DOUX
VERT ÉCLATANT [SZ-05]**

SHAMPOOING DOUX VERT ÉCLATANT [SZ-05]

PHASE	NOM INCI	MARQUE	CONCENTRATION [%]	FONCTION
A	Aqua		jusqu'à	solvant
	Benzophenone-4		0,05	Absorbeur d'UV
	CI 19140		q.s.	colorant
	CI 42090		q.s.	colorant
	Ammonium Laureth Sulfate	SULFOROKAnol®A325/1	35,00	tensioactif
	Ammonium Lauryl Sulfate	ROSULfan® A	15,00	Absorbeur d'UV
	Sodium Benzoate, Potassium Sorbate		0,60	conservateur
	Citric acid		q.s.	modificateur de pH
B	Aqua		1,50	solvant
	Citric acid		0,01	modificateur de pH
	Polyquaternium 10		0,02	agent de conditionnement
C	Parfum		0,50	fragrance
	Cocamidopropyl Betaine	ROKAmina®K30	5,00	tensioactif
	Sodium Chloride		1,80	modificateur de viscosité



pH		4.7 - 5.5
Apparence	méthode visuelle	liquide clair vert clair
Viscosité [cP]	Brookfield LV, broche 34, vitesse 2,5 RPM, T : 25°C	2000 - 5000
Stabilité	1 mois à 5°C, TA, 40°C	confirmé

Procédure:

1. Pendant le mélange, ajoutez de l'acide citrique et du polyquaternium-10 à de l'eau chaude (40-45°C). Mélanger jusqu'à l'obtention d'une solution homogène.
2. Ajouter les ingrédients de la phase A à l'eau tiède (40-45°C). Tout en mélangeant, ajoutez les ingrédients les uns après les autres dans l'ordre du tableau ci-dessus. Mélanger jusqu'à homogénéité.
3. Ajouter la phase B à la phase A. Mélanger jusqu'à obtention d'une solution homogène. Refroidir le lot à 35°C.
4. Ajouter le parfum et la Cocamidopropyl Betaine pendant le mélange. Mélanger jusqu'à l'obtention d'une solution homogène.
5. Si nécessaire, ajouter du chlorure de sodium pour ajuster la viscosité.
6. Contrôlez la plage de pH - si nécessaire, ajoutez de l'acide citrique. Bien mélanger après ajustement.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

