



PENJAGAAN DIRI
RAWATAN MUKA

TOPENG MUKA [KD-120]



TOPENG MUKA [KD-120]

FASA	NAMA INCI	JENAMA	KEPEKATAN [%]	FUNGSI
A	Ceteareth-12	ROKAnol®T12	2,0	pengemulsi
	Ceteareth-25	ROKAnol® T25	0,5	pengemulsi
	Cetearyl alcohol	Serpihan ExoAlc 1618	3,0	penstabil emulsi
	PPG-15 Stearyl ether	ROKAnol® SPI5L	5,0	emolien
	Caprylic/Capric Triglyceride		5,0	emolien
	Glycine Soja Oil		2,5	emolien
	Stearic Acid		1,0	pengubahsuai reologi
	Tocopheryl Acetate		0,5	aktif
	Butyrospermum Parkii Butter		1,0	emolien
B	Aqua		71,5	pelarut
	Pentylene Glycol		2,5	pelarut
	Betaine		1,0	aktif
	Magnesium Aluminum Silicate		1,0	pengubahsuai reologi
C	Kaolin		3,0	penyerap
	Phenoxyethanol, Methylparaben, Ethylparaben, Propylparaben		0,5	bahan pengawet



pH		5.0 – 7.0
Penampilan	kaedah visual	emulsi sedikit kelabu
Kestabilan	1 bulan pada 5°C, RT, 40°C	disahkan

Prosedur:

1. Dalam bekas utama gabungkan bahan-bahan dari fasa B. Tambah Pentylene Glycol, Betaine ke dalam air. Masukkan Magnesium Aluminium Silikat semasa mengadun. Homogen dengan 2000-3000 RPM, 5-6 min.
 2. Dalam bekas berasingan gabungkan bahan-bahan dari fasa A.
 3. Panaskan fasa A dan B kepada 75-80°C.
4. Tambahkan A ke dalam B, sambil mengadun, simpan A/B pada suhu 75-80°C. Homogen dengan 2000-3000 RPM, 120 saat.
 5. Sejukkan batch hingga 50°C semasa mengadun. Masukkan bahan fasa C semasa mengadun. Homogen dengan 2500-3500 RPM, 120 saat.
 6. Sejukkan batch hingga 25°C.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

