



CURA PERSONALE
ALTRO

MOUSSE CORPO BAMBINO [RD-09]



MOUSSE CORPO BAMBINO [RD-09]

FASE	NOME INCI	MARCHIO	CONCENTRAZIONE [%]	FUNZIONE
A	Aqua		44,600	solvente
	Sodium Cocoyl Isethionate		12,000	tensioattivo
	Sodium Lauroyl Sarcosinate	ROKAtend LS	4,500	tensioattivo
	Coco-betaine	ROKAmina®K30B	1,000	tensioattivo
	C12-15 Alkyl Benzoate	EXOsoft AB25	1,000	agente idratante
B	Glycerin		25,000	attivo
	Sorbitol		10,000	attivo
	Panthenol		1,000	attivo
C	Parfum		0,200	fragranza
	CL 17200		0,001	colorante
D	Sodium Benzoate		0,500	conservante
	Potassium Sorbate		0,300	conservante
E	Lactic Acid		0,300	modificatore di pH



Stabilità	1 mese a 5°C, 20°C, 40°C	confermato
Aspetto	metodo visivo	pasta rosa
pH		5.0 - 5.5

Procedura:

1. Aggiungere gli ingredienti della fase A in acqua tiepida (40-45°C). Mescolare fino ad ottenere una soluzione omogenea.
 2. Raffreddare il batch fino ad almeno 35°C.
 3. Aggiungere gli ingredienti della Fase B durante la miscelazione. Mescolare fino ad ottenere una soluzione omogenea.
4. Sempre mescolando, aggiungere gli ingredienti della fase CE. Mescolare fino ad ottenere una consistenza uniforme.
 5. Regolare il pH con acido lattico a un livello di 5,0-5,5.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

