



SOINS PERSONNELS
TRAITEMENT CAPILLAIRE

MASQUE ÉMOLLIENT POUR CHEVEUX [IC-26-02]



MASQUE ÉMOLLIENT POUR CHEVEUX [IC-26-02]

PHASE	NOM INCI	MARQUE	CONCENTRATION [%]	FONCTION
A	Aqua		74,15	solvant
	Cetrimonium Chloride		3,00	agent de conditionnement
	Betaine		2,00	actif
	Glycerin		1,00	humectant
B	Cetearyl Alcohol, Ceteareth-20	Flocons EXOcare®TE20	15,00	émulsifiant
	PPG-15 Stearyl ether	ROKAnol SP15T	2,00	émulsifiant
	Butyrospermum Parkii Butter		1,00	émollient
	Canola Oil		0,50	émollient
C	Parfum		0,50	fragrance
	Phenoxyethanol, Ethylhexylglycerin		0,80	conservateur
D	Sodium Hydroxide	Flocons de soude caustique	0,05	Régulateur de pH



Apparence	méthode visuelle	émulsion blanche
pH		5.0 – 6.0

Procédure:

1. Dans des récipients séparés, mélanger les ingrédients des phases A et B. Chauffer à 60-70 °C. Ajouter la phase A à la phase B tout en mélangeant. Homogénéiser à 2 500-3 500 tr/min, 90-120 secondes.
2. Refroidir le mélange à 30°C tout en mélangeant.
3. Ajouter les phases C et D en mélangeant. Homogénéiser à 1 500 à 2 000 tr/min, 90 à 120 secondes.
4. Vérifiez le pH, si nécessaire, ajoutez plus d'hydroxyde de sodium jusqu'à 5,0 – 6,0.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

