



SOINS PERSONNELS
AUTRE

MOUSSE CORPORELLE POUR ENFANTS [IC-05]



MOUSSE CORPORELLE POUR ENFANTS [IC-05]

PHASE	NOM INCI	MARQUE	CONCENTRATION [%]	FONCTION
A	Aqua		53,9	solvant
	Sodium Cocoyl Isethionate		21,0	tensioactif
	PEG-4 Rapeseedamide	ROKAmid MRZ4	3,0	tensioactif
	Caprylyl/Decyl Glucoside		1,2	tensioactif
	Cocamidopropyl Betaine	ROKAmina®K40HC	1,0	tensioactif
B	Glycerin		11,0	actif
	Sorbitol		6,0	actif
	Betaine		0,4	actif
C	PPG-15 Stearyl ether	ROKAnol ® SP15L	1,0	émollient
	Aqua, Glycerin, Ananas Sativus Fruit Extract, Citric Acid, Sodium Benzoate, Potassium Sorbate		0,4	actif
	Parfum		0,3	fragrance
	CI 15510		q.s.	colorant
D	Sodium Benzoate		0,5	conservateur
D	Potassium Sorbate		0,3	conservateur
E	Lactic Acid		q.s.	Régulateur de pH



Stabilité	1 mois à 5°C, 20°C, 40°C	confirmé
Apparence	méthode visuelle	coller
pH		5.0-5.5

Procédure:

- Ajouter les ingrédients de la phase A à l’eau tiède (40-45°C). Mélanger jusqu’à obtention d’une solution homogène.
 - Refroidir le lot à au moins 35°C.
 - Ajouter la phase B pendant le mélange. Mélanger jusqu’à obtention d’une solution homogène.
- Ajoutez les ingrédients de la phase CD tout en mélangeant et mélangez jusqu’à consistance uniforme.
 - Ajustez le pH avec de l’acide lactique à 5,0-5,5.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

