



OSOBNÍ PÉČE
OŠETŘENÍ TĚLA



ANTIPERSPIRANT
[KD-156]

ANTIPERSPIRANT [KD-156]

FÁZE	JMÉNO INCI	JMÉNO ZNAČKY	KONCENTRACE [%]	FUNKCE
A	Aqua		do	solventní
B	Ceteareth-25, Cetearyl Alcohol	EXOcare®TE25 vločky	3,0	emulgátor
	PPG-15 Stearyl ether	ROKAnol® SPI5L	5,0	změkčující
	Steareth-20	ROKAnol®S20	3,0	emulgátor
C	Aluminum Chlorohydrate		15,0	prostředek proti pocení
	Parfum		0,5	vůně



Stabilita	1 měsíc při 5 °C, 20 °C, 40 °C	potvrzeno
Vzhled	vizuální metoda	bílá emulze
pH		3,5 – 5,0

Postup:

1. V oddělených nádobách smíchejte přísady z fáze A a B. Fáze A homogenizujte: 1500–2000 ot./min. 90–120 s.
2. Fáze A a B se zahřejí na 75–80 °C.
3. Přidejte fázi B k A za míchání. Homogenizace: 1500–2000 RPM 90–120s.
4. Vsázka se za míchání ochladí na 30 °C.
5. Během míchání přidejte složku fáze C. Homogenizace: 1500–2000 RPM 90–120 s.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

