



CURA PERSONALE
PRODOTTI PER LA RASATURA



GEL DOPOBARBA
[KD-356]

GEL DOPOBARBA [KD-356]

FASE	NOME INCI	MARCHIO	CONCENTRAZIONE [%]	FUNZIONE
A	Aqua		fino a	solvente
	Acrylates / C10-30 Alkyl Acrylate Crosspolymer		0,4000	modificatore di reologia
	Allantoin		0,2000	attivo
	CI 42090		0,0001	colorante
B	Sodium Hydroxide		0,3000	regolatore di pH
C	PPG-15 Stearyl ether	ROKAnol® SP15L	3,0000	emolliente
	PPG-5-Ceteth-20	ROKAnol	1,0000	emolliente
	Starch Hydroxypropyl Trimonium Chloride		0,1000	emolliente
	Phenoxyethanol, Ethylhexylglycerin		1,0000	conservante



Stabilità	1 mese a 5°C, 20°C, 40°C	confermato
Aspetto	metodo visivo	gel opaco blu
pH		5.0 - 7.0

Procedura:

1.

Unire gli ingredienti della fase A. Aggiungere lentamente Acrylates/C10-30 Alkyl Acrylate Crosspolymer all'acqua durante la miscelazione. Mescolare fino ad ottenere un composto uniforme. Aggiung altri componenti della fase A. Omogeneizzare con 2000-3000 giri/min, 90-120 sec.
2.

Aggiungere idrossido di sodio (soluzione al 20%) durante la miscelazione. Mescolare fino ad ottenere un composto uniforme.
3.

Aggiungere gli ingredienti della fase C continuando a mescolare. Omogeneizzare con 2000-3000 RPM, 120-180 sec.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

