



OSOBNÁ STAROSTLIVOSŤ
OŠETRENIE TVÁRE

CLEANSING LOTION [KD-348]

BODY TREATMENT
FORMULATION ZONE

pcc

www.products.pcc.eu



*Designed with
Her thought
about you*

ČISTIACA VODA
[KD-348]

ČISTIACA VODA [KD-348]

FÁZA	INCI MENO	NÁZOV ZNAČKY	KONCENTRÁCIA [%]	FUNKCIA
A	Aqua		do	solventný
	Benzyl Alcohol, Ethylhexylglycerin, Tocopherol		0,60	konzervačný prostriedok
	Sclerotium Gum, Xanthan Gum		0,25	modifikátor reológie
	Lactic Acid		0,20	upravovač pH
B	Helianthus Annuus Seed Oil		6,00	zmäkčujúci
	Cetearyl alcohol	ExoAlc 1618 vločky	3,50	stabilizátor emulzie
	Polysorbate 80	ROKwinol 80	3,00	emulgátor
	PPG-15 Stearyl ether	ROKAnol® SPI5L	6,00	zmäkčujúci
	PPG-5-Ceteth-20	ROKAnol®LP6066 MB	2,00	zmäkčujúci
C	Potassium Cocoate	EXOsoft PC35	2,00	povrchovo aktívna látka
	Potassium Oleate	EXOsoft PO30	3,00	povrchovo aktívna látka



Stabilita	1 mesiac pri 5 °C, RT, 40 °C	potvrdil
Vzhľad	emulzia vizuálnej metódy	emulzia
pH		7.5 - 8.5

Postup:

1. V hlavnej nádobe zmiešajte ingrediencie z fázy A. Fázu A zahrejte na 75-80 °C počas miešania.
 2. V samostatnej nádobe zmiešam ingrediencie z fázy B.
 3. Zahrejte fázu B na 75-80 °C.
 4. Pridajte B do A, dobre premiešajte, udržiavajte A/B pri 75-80 °C. Homogenizujte pri 2000-3000 ot./min., 90 sekúnd.
5. Počas miešania sa dávka ochladí na 30 °C.
 6. Pridajte EXOsoft PC35, EXOsoft PO30 – miešajte, kým nebude jednotná.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

