



KİŞİSEL BAKIM  
YÜZ TEDAVİSİ

## DERİNLEMESİNE NEMLENDİRİCİ GÜNDÜZ KREMİ [IC-07]



## DERİNLEMESİNE NEMLENDİRİCİ GÜNDÜZ KREMI [IC-07]

| FAZ | İNCİ ADI                                   | MARKA ADI      | KONSANTRASYON [%] | İŞLEV               |
|-----|--------------------------------------------|----------------|-------------------|---------------------|
| A   | Aqua                                       |                | 78,1              | çözücü              |
|     | Glycerin                                   |                | 3,0               | nemlendirici        |
|     | Trehalose, Hydrolyzed<br>Vegetable Protein |                | 1,0               | aktif               |
|     | Propanediol, Aqua,<br>Bacillus ferment     |                | 1,0               | aktif               |
|     | Panthenol                                  |                | 1,0               | aktif               |
|     | Sclerotium Gum,<br>Xanthan Gum             |                | 0,4               | reoloji değiştirici |
| B   | Cetearyl alcohol                           |                | 2,0               | emülgatör           |
|     | Cetearoth-20                               | ROKAnol®T20    | 2,0               | emülgatör           |
| C   | C12-15 Alkyl Benzoate                      | EXOsoft AB25   | 6,0               | yumuşatıcı          |
|     | PPG-15 Stearyl ether                       | ROKAnol® SP15L | 4,0               | yumuşatıcı          |
|     | Phenoxyethanol                             |                | 0,8               | koruyucu            |
|     | Tocopherol                                 |                | 0,6               | aktif               |
|     | Sodium Polyacrylate                        |                | 0,4               | reoloji değiştirici |
|     | Parfum                                     |                | 0,2               | koku                |



görünüm

görsel yöntem

beyaz emülsiyon

pH

5.0 – 7.0

### prosedür:

1. Bir beher içerisinde Sklerotium ve Ksantan Zamkı'nı Gliserin ile karıştırın.
2. Diğer bir kaptaki Aqua'yı Aktif Madde (faz A) ile birleştirin. Karıştırın ve 60 – 70°C'ye kadar ısıtın. Sclerotium ve Gliserinli Ksantan Sakızı ekleyin.
3. Ana kaptaki B fazını karıştırın ve 60 – 70 °C'ye kadar ısıtın.
4. Faz A'yı faz B'ye ekleyin ve 2500 – 3500 RPM, 90 – 120 sn. ile homojenize edin. Karıştırırken partiyi 40°C'ye kadar soğutun.
5. Sodyum Poliakrilat'ı EXOsoft AB25 ile karıştırın. Kalan faz C'yı ekleyin ve karıştırın.
6. C fazını ana behere ekleyin, 2500 – 3500 RPM, 90 – 120 sn. arasında karıştırın ve homojenize edin.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform  
to check full range of products for personal care.

**[www.products.pcc.eu](http://www.products.pcc.eu)**

PCC Group  
Sienkiewicza 4  
56-120 Brzeg Dolny  
Poland

e-mail: [products@pcc.eu](mailto:products@pcc.eu)

