



SOINS PERSONNELS
TRAITEMENT CAPILLAIRE

APRÈS-SHAMPOING [KD-136]



APRÈS-SHAMPOING [KD-136]

PHASE	NOM INCI	MARQUE	CONCENTRATION [%]	FONCTION
A	Aqua		84,195	solvant
	Cetrimonium Chloride		3,000	agent de conditionnement
	Glycerin		1,000	solvant
	Betaine		2,000	actif
B	Cetearyl Alcohol and Ceteareth-20	Flocons EXOcare®TE20	5,000	émulsifiant
	PPG-15 Stearyl ether	ROKAnol ® SP15L	2,000	émollient
	Glycine Soja Oil		0,500	émollient
C	Dimethicone		1,000	émollient
	Phenoxyethanol, Methylparaben, Ethylparaben, Propylparaben		1,000	conservateur
D	Parfum		0,300	fragrance
E	Sodium Hydroxide		0,005	Ajusteur de pH



pH		5.0 – 6.0
Apparence	méthode visuelle	émulsion blanche
Stabilité	1 mois à 5°C, 20°C, 40°C	confirmé

Procédure:

1. Dans des récipients séparés, combiner les ingrédients des phases A et B. Chauffer jusqu'à 75-80°C. Ajouter la phase B à la phase A tout en mélangeant.

2. Homogénéiser avec 1500-2000 RPM, 90-120 sec.

3. Refroidir le lot à 70°C tout en mélangeant. Ajouter les ingrédients C tout en mélangeant. Homogénéiser avec 1500-2000 RPM, 90-120 sec.
4. Refroidir le lot à 30°C tout en mélangeant. Ajouter les autres ingrédients tout en mélangeant. Homogénéiser avec 1500-2000 RPM, 90-120 sec.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

