



CUIDADO PESSOAL
TRATAMENTO FACIAL



LAVAGEM FACIAL DE
DUAS FASES DE ESPUMA
[ST-05]

LAVAGEM FACIAL DE DUAS FASES DE ESPUMA [ST-05]

ESTÁGIO	NOME DA INCI	MARCA	CONCENTRAÇÃO [%]	FUNÇÃO
A	Aqua		38,4	solvente
	Sodium Lauroyl Glycinate	ROKAtend GL	10,0	surfactante
	Sodium Lauroyl Sarcosinate	ROKAtend LS	30,0	surfactante
	Propylene Glycol		3,0	solvente
	Parfum		0,6	fragrância
	Ethylhexyl Glycerine, Phenoxyethanol		1,0	conservante
	PEG-7 Glyceryl Cocoate	rokacet-ko300g	1,6	agente de relubrificação
	Mineral Oil		15,0	emoliente
	Citric acid		0,4	modificador de pH



pH		6.0 - 7.5 (water phase)
Aparência	método visual	líquido límpido e incolor
estabilidade	1 mês a 5°C, RT, 40°C	confirmado

Procedimento:

1. Adicione os ingredientes da fase A à água morna (40-50°C). Misture até ficar uniforme.
 2. Em seguida, esfrie a mistura até a temperatura ambiente antes de adicionar um conservante e adicione o restante dos ingredientes.
 3. Controle a faixa de pH – se necessário, adicione ácido cítrico. Misture bem após o ajuste.
4. Adicione cloreto de sódio para ajustar a viscosidade. OBSERVAÇÃO. Adicione sal (não de uma só vez) – após a adição de cada porção, misture bem.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

