



CURA PERSONALE
TRATTAMENTO VISO

MILD PEARLING GEL FOR SKIN FACE [ST-06]

FACE TREATMENT
FORMULATION ZONE

pcc

www.products.pcc.eu



*Designed with
the thought
about you.*

**GEL DELICATO PERLATO
PER LA PELLE DEL VISO
[ST-06]**

GEL DELICATO PERLATO PER LA PELLE DEL VISO [ST-06]

FASE	NOME INCI	MARCHIO	CONCENTRAZIONE [%]	FUNZIONE
A	Aqua		45,90	solvente
	Xanthan Gum		0,65	modificatore di viscosità
	Glycerin		2,00	agente idratante
	Sodium Benzoate, Potassium Sorbate		0,60	conservante
B	Aqua		15,70	solvente
	Magnesium Laureth Sulfate	EXOsoft MGB	20,00	tensioattivo
	Sodium Lauroyl Sarcosinate	ROKAtend LS	10,00	tensioattivo
	Cocamidopropyl Betaine	ROKAmina®K30	3,40	tensioattivo
C	Citric acid		0,25	modificatore di pH
	Sodium Laureth Sulfate and Cocamide DEA and Glycol Distearate	EXOpearl N	1,00	agente perlante
	Parfum		0,50	fragranza



pH		4.8 – 5.5
Aspetto	metodo visivo	gel viscoso perlato
Viscosità [cP]	Brookfield LV, mandrino 34, velocità 4,0 RPM, T: 25°C	6000 – 9000
Stabilità	1 mese a 5°C, TA, 40°C	confermato

Procedura:

1. In un recipiente principale unire gli ingredienti della fase A. Aggiungere la gomma di xantano alla glicerina - mescolare fino ad ottenere una soluzione omogenea. Aggiungere acqua tiepida (40-50°C) e conservante. Mescolare fino ad ottenere una soluzione omogenea. Omogeneizzare per 2-3 minuti.
 2. Unire gli ingredienti della fase B. Aggiungere gli ingredienti della fase B all'acqua calda (40-45°C). Mescolare fino ad ottenere una soluzione omogenea.
3. Aggiungere la fase B alla fase A. Mescolare fino ad ottenere una soluzione omogenea. Raffreddare il lotto fino a 30°C.
 4. Regola il pH a 4,8 – 5,5 usando l'acido citrico. Mescolare bene dopo la regolazione.
 5. Aggiungere gli ingredienti della fase C. Mescolare fino ad ottenere una soluzione omogenea.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

