



SOINS PERSONNELS
SOIN DU VISAGE

MAKE-UP REMOVING MILK [KD-85]

FACE TREATMENT
FORMULATION ZONE

pcc

www.products.pcc.eu



*Designed with
the thought
about you*

LAIT DEMAQUILLANT
[KD-85]

LAIT DEMAQUILLANT [KD-85]

PHASE	NOM INCI	MARQUE	CONCENTRATION [%]	FONCTION
A	Ceteareth-12	ROKAnol®T12	1,00	émulsifiant
	Ceteareth-25	ROKAnol® T25	1,00	émulsifiant
	Cetearyl alcohol		2,00	stabilisateur d'émulsion
	PPG-15 Stearyl ether	ROKAnol ® SP15L	5,00	émollient
	Helianthus Annuus Seed Oil		1,00	émollient
	Caprylic/Capric Triglyceride		2,00	émollient
B	Aqua		83,35	solvant
	Betaine		0,50	actif
C	Glycerin		1,00	agent hydratant
	Xanthan Gum		0,05	Ajusteur de pH
D	Carbomer		0,25	modificateur de rhéologie
E	Sodium Hydroxide		0,05	Ajusteur de pH
	Phenoxyethanol, Methylparaben, Ethylparaben, Propylparaben		0,80	conservateur
F	PEG-7/PPG-2 Propylheptyl ether	ROKAnol® GA7LAW	2,00	solvant



pH		5.0 – 7.0
Apparence	méthode visuelle	émulsion blanche
Stabilité	1 mois à 5°C, TA, 40°C	confirmé

Procédure:

1. Dans un récipient séparé, je combine les ingrédients des phases A, B et C.
2. Ajouter lentement les ingrédients de la phase D à la phase B tout en mélangeant. Mélanger jusqu'à homogénéité.
3. Ajouter lentement les ingrédients de la phase C à la phase B tout en mélangeant. Homogénéiser avec 2000-3000 RPM, 90 sec.
4. Chauffer les phases A et B à 75-80°C.
5. Ajouter A dans B, bien remuer à la main, maintenir A/B à 75-80°C. Homogénéiser avec 2000-3000 RPM, 120 sec.
6. Refroidir le lot à 50°C tout en mélangeant. Ajouter les ingrédients de la phase E tout en mélangeant. Homogénéiser avec 2500-3500 RPM, 90 sec.
7. Refroidir le lot à 25°C. Ajouter les ingrédients de la phase F tout en mélangeant. Homogénéiser avec 2500-3500 RPM, 90 sec.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

