



SOINS PERSONNELS
SOIN DU VISAGE

CRÈME DE JOUR HYDRATANTE EN PROFONDEUR [HPCI-02]



CRÈME DE JOUR HYDRATANTE EN PROFONDEUR [HPCI-02]

PHASE	NOM INCI	MARQUE	CONCENTRATION [%]	FONCTION
A	Aqua		78,1	solvant
	Glycerin		3,0	humectant
	Trehalose, Hydrolyzed Vegetable Protein		1,0	actif
	Propanediol, Aqua, Bacillus ferment		1,0	actif
	Panthenol		0,5	actif
	Sclerotium Gum, Xanthan Gum		0,4	modificateur de rhéologie
B	Cetearyl alcohol		2,0	émulsifiant
	Ceteareth-20	ROKAnol®T20	2,0	émulsifiant
C	C12-15 Alkyl Benzoate	EXOsoft AB25	6,0	émollient
	PPG-15 Stearyl ether	ROKAnol ® SP15L	4,0	émollient
	Phenoxyethanol		0,8	conservateur
	Tocopherol		0,6	actif
	Sodium Polyacrylate		0,4	modificateur de rhéologie
	Parfum		0,2	fragrance



Apparence	méthode visuelle	émulsion blanche
pH		5.0 – 7.0

Procédure:

1. Dans un bécher, mélanger le sclérote et la gomme xanthane avec la glycérine.
 2. Dans un autre bécher, mélanger l'eau avec la substance active (phase A). Mélanger et porter à 60-70 °C. Ajouter le sclérote, la gomme xanthane et la glycérine.
 3. Dans le récipient principal, mélanger la phase B et chauffer jusqu'à 60 – 70 °C.
 4. Ajouter la phase A à la phase B et homogénéiser à 2 500 à 3 500 tr/min, 90 à 120 secondes. Refroidir le mélange à 40 °C tout en mélangeant.
5. Mélanger le polyacrylate de sodium avec EXOsoft AB25. Ajouter la phase C restante et mélanger.
 6. Ajouter la phase C au bécher principal, mélanger et homogénéiser à 2500 – 3500 tr/min, 90 – 120 secondes.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

