



CUIDADO PERSONAL
TRATAMIENTO FACIAL

CREMA DE DÍA HIDRATANTE PROFUNDAMENTE [HPCI-02]



CREMA DE DÍA HIDRATANTE PROFUNDAMENTE [HPCI-02]

FASE	NOMBRE INCI	NOMBRE DE LA MARCA	CONCENTRACIÓN [%]	FUNCIÓN
A	Aqua		78,1	solvente
	Glycerin		3,0	humectante
	Trehalose, Hydrolyzed Vegetable Protein		1,0	activo
	Propanediol, Aqua, Bacillus ferment		1,0	activo
	Panthenol		0,5	activo
	Sclerotium Gum, Xanthan Gum		0,4	modificador de reología
B	Cetearyl alcohol		2,0	emulsionante
	Ceteareth-20	ROKAnol® T20	2,0	emulsionante
C	C12-15 Alkyl Benzoate	EXOsoft AB25	6,0	emoliente
	PPG-15 Stearyl ether	ROKAnol® SP15L	4,0	emoliente
	Phenoxyethanol		0,8	preservativo
	Tocopherol		0,6	activo
	Sodium Polyacrylate		0,4	modificador de reología
	Parfum		0,2	fragancia



apariencia	metodo visual	emulsión blanca
pH		5.0 – 7.0

Procedimiento:

1. En un vaso medidor mezcle esclerocio y goma xantana con glicerina.
 2. En otro vaso, combine el agua con la sustancia activa (fase A). Mezcle y caliente a 60-70 °C. Añada esclerocio y goma xantana con glicerina.
 3. En el recipiente principal mezclar la fase B y calentar a 60 – 70 °C.
 4. Añadir la fase A a la fase B y homogeneizar a 2500-3500 RPM, 90-120 s. Enfriar la mezcla a 40 °C mientras se mezcla.
5. Mezcle el poliacrilato de sodio con EXOsoft AB25. Añada la fase C restante y mezcle.
 6. Añadir la fase C al vaso principal, mezclar y homogeneizar con 2500 – 3500 RPM, 90 – 120 segundos.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

