



PERSOONLIJKE VERZORGING
GEZICHTSBEHANDELING

GEZICHTSMASKER [KD-120]



GEZICHTSMASKER [KD-120]

FASE	INCI NAAM	MERKNAAM	CONCENTRATIE [%]	FUNCTIE
A	Ceteareth-12	ROKAnol®T12	2,0	emulgator
	Ceteareth-25	ROKAnol® T25	0,5	emulgator
	Cetearyl alcohol	ExoAlc 1618 vlokken	3,0	emulsie stabilisator
	PPG-15 Stearyl ether	ROKAnol® SP15L	5,0	verzachtend
	Caprylic/Capric Triglyceride		5,0	verzachtend
	Glycine Soja Oil		2,5	verzachtend
	Stearic Acid		1,0	reologie modifierator
	Tocopheryl Acetate		0,5	actief
	Butyrospermum Parkii Butter		1,0	verzachtend
B	Aqua		71,5	oplosmiddel
	Pentylene Glycol		2,5	oplosmiddel
	Betaine		1,0	actief
	Magnesium Aluminum Silicate		1,0	reologie modifierator
C	Kaolin		3,0	absorberend
	Phenoxyethanol, Methylparaben, Ethylparaben, Propylparaben		0,5	conserveermiddel



pH		5.0 – 7.0
Uiterlijk	visuele methode	lichtgrijze emulsie
stabiliteit	1 maand bij 5°C, KT, 40°C	bevestigd

Procedure:

1. Combineer ingrediënten uit fase B in een hoofdvat. Voeg pentyleenglycol, betaïne toe aan het water. Voeg tijdens het mengen magnesium-aluminiumsilicaat toe. Homogeniseren met 2000–3000 RPM, 5–6 min.
2. Combineer ingrediënten uit fase A in een apart vat.
3. Verwarm fase A en B tot 75–80°C.
4. Voeg A toe aan B, terwijl je mixt, houd A/B op 75–80°C. Homogeniseren met 2000–3000 RPM, 120 sec.
5. Koel de batch al roerend af tot 50°C. Voeg fase C-ingrediënten toe tijdens het mixen. Homogeniseren met 2500–3500 RPM, 120 sec.
6. Koel de batch af tot 25°C.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform
to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

