



PERSONAL CARE
BODY TREATMENT



MILD YELLOW HAND SOAP [MP-03]

MILD YELLOW HAND SOAP [MP-03]

| PHASE | INCI | BRAND NAME | CONCENTRATION [%] | FUNCTION |
|-------|---|--------------|-------------------|--------------------|
| A | Aqua | | 46,55 | solvent |
| | Potassium Oleate | | 8,00 | surfactant |
| | Sodium Lauroyl Glycinate | ROKAtend GL | 25,00 | surfactant |
| | Decyl Glucoside | | 7,00 | surfactant |
| B | Citric acid | | 0,20 | pH modifier |
| C | Parfum | | 0,50 | fragrance |
| | Benzy Alcohol, Ethylhexylglycerin, Tocopherol | | 1,00 | preservative |
| | Cocamidopropyl Betaine | ROKAminc®K30 | 10,00 | surfactant |
| | Sodium Chloride | | 1,75 | viscosity modifier |



| | | |
|----------------|---|---------------|
| pH | | 8.5 - 9.0 |
| Apperance | visual method | yellow liquid |
| Viscosity [cP] | Brookfield LV, spindle 34, speed 2.5 RPM, T: 25°C | 3000 - 5000 |
| Stablility | 1 month at 5°C, RT, 40°C | confirmed |

Procedure:

1. Into the large vessel (big enough to provide adequate mixing while preparing batch) pour deionized water.
2. Add ingredients from phase A to the vessel while mixing. Heat up to 70 - 75°C. Mix until homogenous solution is obtained.
3. Cool the batch down to at least 35°C.
4. Adjust pH to 8.5 - 9.0 by using Citric Acid. Mix well after adjustment.
5. Add fragrance, preservative and Cocamidopropyl Betaine. Mix until homogenous solution is obtained.
6. If necessary, add Sodium Chloride to adjust the viscosity. NOTE: it is very important to equilibrate a sample at 25°C for at least one hour to get an accurate viscosity measurement.



The information in the catalogue is believed to be accurate and to the best of our knowledge, but should be considered as introductory only. Detailed information about products is available in TDS and MSDS. Suggestions for product applications are based on our the best of our knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application and for determining product suitability for your own purposes rests with the user.

All copyright, trademark rights and other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA, PCC EXOL SA and other companies of the PCC Group or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply in respect to data used in other publications, in electronic information systems, or in other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.

Please visit our capital group business platform to check full range of products for personal care.

www.products.pcc.eu

PCC Group
Sienkiewicza 4
56-120 Brzeg Dolny
Poland

e-mail: products@pcc.eu

